

Conductive Caster Carts

NOTICE

Special Assembly Instructions

1. Unpack cartons to confirm amount and identity of components.
2. Use the standard assembly instructions as a guide to assemble the unit.
Aluminum split sleeves **must** be used when assembling Super Erecta style shelves to the posts.
3. Identify the top shelf of the unit by the special warning sign attached to one end. This shelf **must** be assembled on the unit with this warning sign facing the operator.
If the unit has a handle, the sign **must** be on the same end as the handle. If the unit has two rigid and two swivel casters, the sign **must** be on the same end as the swivel casters.
4. Test conductivity of the casters per instructions provided.

**InterMetro Industries Corporation**

North Washington Street, Wilkes-Barre, PA 18705

For Product Information Call: 1-800-433-2232

Visit Our Web Site: www.metro.com

L01-018

5/01

Information and specifications are subject to change without notice. Please confirm at time of order.