

**ASSEMBLY INSTRUCTIONS FOR HIGH TEMPERATURE KIT PART NO. HTK-1**

WITH THIS KIT, THE (CBH BENCHSIDE) MODEL CAN WITHSTAND TEMPERATURES OF 350° F (177°C), (CBH TRANS-STOR, CBL & CBV) MODELS CAN WITHSTAND TEMPERATURES OF 250° F (121° C). NOTE: WHEN THE CART IS EXPOSED TO TEMPERATURES IN EXCESS OF 325° F (160° C), FOR LONG PERIODS OF TIME, SOME DEGRADATION OF THE NUMBER STRIP LABELS WILL BE EXPERIENCED. IF DESIRED, THESE LABELS CAN BE REMOVED.

<b>CONTENTS:</b>	<b><u>DESCRIPTION</u></b>	<b><u>QTY.</u></b>
	CASTER	2
	CASTER W/ BRAKE	2
	METAL POST CAP	4
	CAUTION HOT LABEL	2
	ALUMINUM SPLIT SLEEVES W/ C-RINGS	3 BAGS

- 1.) UNPACK THE CARTON TO CONFIRM AMOUNT AND IDENTIFY THE COMPONENTS.
- 2.) PRY OUT THE GRAY PLASTIC CAP ON THE TOP OF EACH POST AND REPLACE IT WITH THE METAL POST CAP.
- 3.) INSTALL THE CASTERS INTO THE POSTS FOLLOWING THE INSTRUCTIONS SUPPLIED WITH THE TRUCK.
- 4.) DO NOT INSTALL THE DONUT BUMPERS ONTO THE POSTS.
- 5.) FOLLOW THE TRUCK ASSEMBLY PROCEDURES AS OUTLINED, REPLACING THE CONDUCTIVE SPLIT SLEEVES W/ ALUMINUM SPLIT SLEEVES AND C-RINGS.
- 6.) AFFIX THE CAUTION HOT LABELS TO THE PANELS OR FRAMES.