



NOTICE

Special Assembly Instructions

1. Unpack cartons to confirm amount and identity of components.
2. Use the standard assembly instructions as a guide to assemble the unit. Aluminum split sleeves **must** be used when assembling the shelves to the posts.
3. Identify the top shelf of the unit by the special warning sign attached to one end. This shelf **must** be assembled on the unit with this warning sign facing the operator. If the unit has a handle, the sign **must** be on the same end as the handle. If the unit has two rigid and two swivel casters, the sign must be on the same end as the swivel casters.
4. Test conductivity of the casters per the instructions provided.