



Item # _____

Job _____

HD SUPER™ SOLID SHELVING

- **Extra Strong:** HD Super™ shelving employs the patented, proven Super Erecta Shelf® principle with large diameter posts and heavy gauge shelves.
- **Easy to Assemble:** Units can be put together in minutes without special tools. Tapered plastic sleeves lock into position on grooved posts and fit into the matching taper in the cast corners of the shelf, providing a positive lock. Shelves are adjustable in 2" (51mm) intervals and can be repositioned if use changes.
- **Several Shelf Options:** Heavy-duty solid shelves are available in flat or louvered/embossed styles in galvanized or stainless steel. Choose from 18" or 24" (455 or 610mm) widths and lengths ranging from 36" to 60" (910 to 1525mm). Shelves are made of heavy-duty 16-gauge steel.
- **Posts Provide Greater Rigidity:** HD Super™ posts have an outside diameter of 1⁵/₈" (42mm) providing 28% to 128% greater rigidity than posts of lesser diameter on other makes of modular shelving. Posts are available in chrome-plated, stainless steel, or Metroseal II.
- **Stationary or Mobile:** Standard units are stationary with leveling foot on each post. Posts are also available fitted with 5" (127mm) polyurethane swivel or brake casters. (Recommended load capacity for mobile units is 1,000 lbs. [454kg] gross cart weight.)





HD SUPER™ SOLID SHELVING

Specifications

- **Shelves:** Shelves are 16-gauge galvanized or T-304 stainless steel. Popular sizes in flat galvanized and flat stainless are stocked. Louvered/embossed is available in both galvanized and stainless.
- **Posts:** Steel posts have an outside diameter of 1⁵/₈" (42mm), with rolled grooves in 2" (51mm) increments along entire height. Available in chrome-plated, Metroseal II or stainless steel.
- **Posts with Casters:** Special posts are available fitted with 5" (127mm) donut bumpers and 5" (127mm) polyurethane swivel (5HHP) or swivel/brake (5HHPB) casters if desired.
- **Load Rating:** 1,000 lbs. (454kg) equally distributed.

Dimensions

Shelves — 16 gauge

FLAT

Cat. No. Galvanized	Cat. No. Stainless	Width/Length		Approx. Pkd. Wt.	
		(in.)	(mm)	(lbs.)	(kg)
1836HFG	1836HFS	18x36	455x910	21	9.5
1842HFG	1842HFS	18x42	455x1060	23	10.4
1848HFG	1848HFS	18x48	455x1220	26	11.7
1854HFG	1854HFS	18x54	455x1370	28	12.7
1860HFG	1860HFS	18x60	455x1525	31	14.0
2436HFG	2436HFS	24x36	610x910	25	11.3
2442HFG	2442HFS	24x42	610x1060	29	13.1
2448HFG	2448HFS	24x48	610x1220	32	14.4
2454HFG	2454HFS	24x54	610x1370	35	15.8
2460HFG	2460HFS	24x60	610x1525	38	17.1

LOUVERED/EMBOSSSED*

Cat. No. Galvanized	Cat. No. Stainless	Width/Length		Approx. Pkd. Wt.	
		(in.)	(mm)	(lbs.)	(kg)
—	1836HLS	18x36	455x910	21	9.5
—	1842HLS	18x42	455x1060	23	10.4
—	1848HLS	18x48	455x1220	26	11.7
—	1854HLS	18x54	455x1370	28	12.7
—	1860HLS	18x60	455x1525	31	14.0
—	2436HLS	24x36	610x910	25	11.3
—	2442HLS	24x42	610x1060	29	13.1
—	2448HLS	24x48	610x1220	32	14.4
—	2454HLS	24x54	610x1370	35	15.8
—	2460HLS	24x60	610x1525	38	17.1

*On special order only.

HD Super™ Posts for Stationary Units

Cat. No. Chrome	Cat. No. Metroseal II	Cat. No. Stainless	Height*		Approx. Pkd. Wt.	
			(in.)	(mm)	(lbs.)	(kg)
54HPC	54HPK2	54HPS	54	1421	5.8	2.6
63HPC	63HPK2	63HPS	64	1624	6.3	2.9
74HPC	74HPK2	74HPS	76	1929	7.5	3.4

*Height includes leveling foot and cap.

Manufactured by:



InterMetro Industries Corporation

North Washington Street, Wilkes-Barre, PA 18705

Phone: 570-825-2741 • Fax: 570-825-2852

For Product Information Call: 1-800-433-2232

Visit Our Web Site: www.metro.com

L02-030
Rev. 9/00
Printed in U.S.A.

Information and specifications are subject to change without notice. Please confirm at time of order.

