Job			

Item #

HD SUPER™ SOLID SHELVING

- Extra Strong: HD Super[™] shelving employs the patented, proven Super Erecta Shelf[®] principle with large diameter posts and heavy gauge shelves.
- Easy to Assemble: Units can be put together in minutes without special tools. Tapered plastic sleeves lock into position on grooved posts and fit into the matching taper in the cast corners of the shelf, providing a positive lock. Shelves are adjustable in 2" (51mm) intervals and can be repositioned if use changes.
- Several Shelf Options: Heavy-duty solid shelves are available in flat or louvered/embossed styles in galvanized or stainless steel. Choose from 18" or 24" (457 or 610mm) widths and lengths ranging from 36" to 60" (914 to 1524mm). Shelves are made of heavy-duty 16-gauge steel.
- Posts Provide Greater Rigidity: HD Super[™] posts have an outside diameter of 1⁵/₈" (42mm) providing 28% to 128% greater rigidity than posts of lesser diameter on other makes of modular shelving. Posts are available in chrome-plated or stainless steel.
- Stationary or Mobile: Standard units are stationary with leveling foot on each post. Posts are also available fitted with 5" (127mm) polyurethane swivel or brake casters. (Recommended load capacity for mobile units is 1,000 lbs. [454kg] gross cart weight.)







HD Super™ Solid Shelving

HD SUPER™ SOLID SHELVING



Specifications

- Shelves: Shelves are 16-gauge galvanized or T-304 stainless steel. Louvered/embossed is available in stainless steel.
- Posts: Steel posts have an outside diameter of 15/8" (42mm), with rolled grooves in 2" (51mm) increments along entire height. Available in chrome-plated or stainless steel.
- Posts with Casters: Special posts are available

fitted with 5" (127mm) donut bumpers and 5" (127mm) polyurethane swivel (5HHP) or swivel/brake (5HHPB) casters if desired.

• Load Rating:

Shelf: 1,000 lbs. (454kg) evenly distributed per shelf, not to exceed unit load rating.

Stationary - 3,000 lbs. (1363 kg.) evenly distributed.

Mobile - 1,000 lbs. (454 kg) with casters.

Dimensions

Shelves — 16 gauge

FLAT

Cat. No.	Cat. No.	Width/Length		Approx. Pkd. Wt.	
Galvanized	Stainless	(in.)	(mm)	(lbs.)	(kg)
1836HFG	1836HFS	18x36	457x914	21	9.5
1842HFG	1842HFS	18x42	457x1066	23	10.4
1848HFG	1848HFS	18x48	457x1219	26	11.7
1854HFG	1854HFS	18x54	457x1370	28	12.7
1860HFG	1860HFS	18x60	457x1524	31	14.0
2436HFG	2436HFS	24x36	610x914	25	11.3
2442HFG	2442HFS	24x42	610x1066	29	13.1
2448HFG	2448HFS	24x48	610x1219	32	14.4
2454HFG	2454HFS	24x54	610x1370	35	15.8
2460HFG	2460HFS	24x60	610x1524	38	17.1

LOUVERED/EMBOSSED*

Cat. No.	Widt	h/Length	Approx. Pkd. Wt.		
Stainless	(in.)	(mm)	(lbs.)	(kg)	
1836HLS	18x36	457x914	21	9.5	
1842HLS	18x42	457×1066	23	10.4	
1848HLS	18x48	457×1219	26	11.7	
1854HLS	18x54	457×1370	28	12.7	
1860HLS	18x60	457×1524	31	14.0	
2436HLS	24x36	610x914	25	11.3	
2442HLS	24x42	610×1066	29	13.1	
2448HLS	24x48	610×1219	32	14.4	
2454HLS	24x54	610×1370	35	15.8	
2460HLS	24x60	610x1524	38	17.1	

HD Super™ Posts for Stationary Units

Cat. No.	Cat. No.	Hei	ght*	Approx. Pko	d. Wt.	
Chrome	Stainless	(in.)	(mm)	(lbs.)	(kg)	
54HPC	54HPS	54	1421	5.8	2.6	
63HPC	63HPS	64	1624	6.3	2.9	
74HPC	74HPS	76	1929	7.5	3.4	

All Metro Catalog Sheets are available on our Web Site: www.metro.com



InterMetro Industries Corporation North Washington Street, Wilkes-Barre, PA 18705 Phone: 570-825-2741 • Fax: 570-825-2852

For Product Information Call: 1-800-433-2232

Printed in U.S.A. Rev. 4/09

Information and specifications are subject to change without notice. Please confirm at time of order Copyright © 2007 InterMetro Industries Corp.