

Metro C5 T-Series Correctional Package

Takes a Beating ... and Keeps on Heating™

Real Life Testing!



Durable, Efficient, Intelligent. Stainless steel construction with foamed-in-place polyurethane insulation provides superior rigidity for correctional applications!

Steel Reinforced Handles and polymer armour panels, that double as bumpers to protect the cabinet and facilitate handling.

Lockable Control Panel Cover restricts access and protects controls.

Lockable Travel Latch / Hasp keeps cabinet contents secure while unattended.

Vaulted Door with flush mount paddle latch provides maximum structural integrity.

Concealed Hinges 11 gauge stainless steel, with welded non-removable 3/8" pin, and reinforced backer plates.

Heavy Duty One-Piece Base 6" casters bolted to heavy duty caster channels, reinforced with foamed-in-place insulation.

Tamper Proof Screws on cabinet exterior.



EMERSON. CONSIDER IT SOLVED.™