



Item # _____

Job _____



LINEN TRUCK CLT SERIES

- **Versatile Construction:** By positioning the two folding shelves on the CLT – either horizontally or vertically – three different truck configurations become possible:

- #1. Folding shelves can be positioned horizontally for easy transport and accessibility for fresh linen. (35-40-bed capacity)
- #2. Folding shelves can be positioned vertically to become an enclosure panel, creating a spacious rolling bin for the collection and the transportation of soiled linen.
- #3. While folding shelves are in a vertical position, the lower folding shelf can be flipped out and up, enabling contents to be unloaded with a minimum amount of handling.

Note: See illustrations on back.

- **Open Wire Features:** Minimize dust accumulation and allow a free circulation of air, greater visibility of stored items and greater light penetration.
- **Brake Lock/Swivel Lock Combination Casters:** Enable a single pair of casters to serve as swivel, rigid or brake casters to meet varying operational needs. See sheet #11.70.
- **Covers Available:** Catalog numbers on reverse side. See sheet #11.80.
- **Pitched Aluminum Dust Cover:** Shields lower truck contents against dust or dirt.
- **Cart-Washable**



Heavy-Duty

Heavy-duty models contain heavier gauge corner posts and two additional intermediate frames.



Standard-Duty



InterMetro Industries Corporation
North Washington Street
Wilkes-Barre, PA 18705
www.metro.com



LINEN TRUCK CLT SERIES



Dimensions

Model No.	Description	Width		Shelf Size		Length		Height	
		(in.)	(mm)	(in.)	(mm)	(in.)	(mm)	(in.)	(mm)
STANDARD-DUTY CHROME									
CLTS2460C	CLT with 3-sided top frame	24	610	60	1524	70	1775		
CLTS2448C	CLT with 3-sided top frame	24	610	48	1219	70	1775		
STANDARD-DUTY - STAINLESS STEEL									
CLT2460S	CLT with 3-sided top frame	24	610	60	1524	70	1775		
HEAVY-DUTY - CHROME									
CLTH2460C	CLT with 3-sided top frame	24	610	60	1524	70	1775		

Material: Chrome Models: chrome-plated steel dolly and aluminum tubes. Stainless Steel: stainless steel dolly and aluminum tubes.

Note 1: Casters on above units consist of two 6P and one pair BL6P, 8P and BL8P available on special order.

Note 2: Before employing any of various cart-washing systems, please contact InterMetro representative for special recommendations on casters and for cleaning instructions.

Accessories

UNCOATED COVERS

Width		Length		Height		Zippered Closure	Velcro Closure
(in.)	(mm)	(in.)	(mm)	(in.)	(mm)	Cat. No.	Cat. No.
24	610	48	1219	62	1575	24x48x62UC	24x48x62VUC
24	610	60	1524	62	1575	24x60x62UC	24x60x62VUC

COATED COVERS

Width		Length		Height		Zippered Closure	Velcro Closure
(in.)	(mm)	(in.)	(mm)	(in.)	(mm)	Cat. No.	Cat. No.
24	610	48	1219	62	1575	24x48x62C	24x48x62VC
24	610	60	1524	62	1575	24x60x62C	24x60x62VC

All Metro Catalog Sheets are available on our Web Site: www.metro.com



InterMetro Industries Corporation

North Washington Street, Wilkes-Barre, PA 18705
Phone: 570-825-2741 • Fax: 570-825-2852

For Product Information Call: 1-800-433-2232

L02-159
Printed in U.S.A. Rev. 4/02

Information and specifications are subject to change without notice. Please confirm at time of order.

Copyright © 2002 InterMetro Industries Corp.

