



Item # _____

Job _____

BASIX PLUS™ COMPACT

Efficient storage plus lighter, cleaner, easier

Basix Plus Compact is constructed from a combination of materials to endure the rigors of a daily routine while providing a safe, ergonomic and flexible work area for the user. The cabinet is made of steel to provide a solid structure. The drawers are made from aluminum to reduce the overall weight of the cart. The polymer base reduces overall weight and provides impact protection to the cart and surrounding environment.

- **Compact** — This cart is ideal for close quarters. The cart provides a compact footprint of 22½" x 24" (572 x 610mm).
- **Lighter** — Basix Plus Compact carts are made lighter than typical all-steel carts by utilizing aluminum drawers and polymer components such as the polymer base, cart top and corner extrusions.
- **Cleaner** — Polymer corner extrusions provide accessory attachment channels that are accessible for cleaning. The cart's steel shell is not compromised by pre-drilled holes.
- **Easier** — Lighter weight carts are easier to push, and reduce back strain. Accessible accessory channels are easier to clean. Accessory attachment panel provides flexibility for easier accessory positioning.
- **Safe** — The base allows the casters to be mounted outboard of the cabinet providing an anti-tip mechanism. The polymer base doubles as the cart's bumper.
- **Ergonomic** — Push handles are molded into to the polymer cart top providing a natural position to either push or pull the cart. Cart top has a contoured front lip to provide a comfortable work space.
- **Flexible** — User defined configurations can be accommodated by filling an empty cart shell with desired drawer heights. Choose from 3", 6", and 9" (76, 152, and 229mm) drawer heights.
- **Accessible** — Full-extension drawers and a full array of accessories put equipment and supplies where needed for convenient access.



MBPC3110TL, MBC-YE (Yellow) with Accessories



MBPC3210TL, MBC-LT (Light Taupe) with Accessories



Basix Plus™ Compact



InterMetro Industries Corporation
North Washington Street
Wilkes-Barre, PA 18705
www.metro.com



36.40



BASIX PLUS™ COMPACT

Dimensions

M	B	P	3	1	1	0	S	N
Metro	Basix	Plus	3" Drawers	6" Drawers	9" Drawers	12" Drawers	Color Tone ¹	Lock Type ²
¹ Color Tone: S - Solid — Cart body color matches drawer front color T - Two Tone — Cart body color is light taupe ² Lock Type: L - Keyed Lock								

Carts and Drawers

Model No.	Drawer Space (in.) (mm)	Drawer Configuration	Color	Lock	Height (in.) (mm)	Width (in.) (mm)	Length (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)
MBPC3110TL	24 610	3 - 3"; 1 - 6"; 1 - 9"	Two Tone	Key Lock	38 965	22½ 572	24 610	133 63
MBPC1210TL	24 610	1 - 3"; 2 - 6"; 1 - 9"	Two Tone	Key Lock	38 965	22½ 572	24 610	133 63
MBPC3210TL	30 762	3 - 3"; 2 - 6"; 1 - 9"	Two Tone	Key Lock	44 1118	22½ 572	24 610	133 63

M	B	P	24	S	N
Metro	Basix	Plus	Vertical Drawer Space (in.)	Color Tone	Lock Type

Empty Carts

Model No.	Drawer Space (in.) (mm)	Height (in.) (mm)	Width (in.) (mm)	Length (in.) (mm)
MBPC24TL	24 610	38 965	22½ 572	24 610
MBPC30TL	30 762	44 1118	22½ 572	24 610

Drawers

Model No.	Description	Interior Dimensions			Weight Capacity (lbs.) (kg)
		Height (in.) (mm)	Width (in.) (mm)	Length (in.) (mm)	
MBPC103	3" (76mm) Deep Drawer	2⅞ 73	16½ 432	15 381	50 24
MBPC106	6" (152mm) Deep Drawer	6¼ 159	16½ 432	15 381	50 24
MBPC109	9" (229mm) Deep Drawer	9⅞ 238	16½ 432	15 381	50 24

Accessories

Model No.	Description	Height (in.) (mm)	Width (in.) (mm)	Length (in.) (mm)
MBPC210	Cart Top Rail	5 127	21 533	17¾ 451
MBPC511	Overbridge			

Colors





BASIX PLUS™ COMPACT

Specifications

Cart Body:	Double wall construction Inner wall: 22 gauge (.030"/.8mm) steel Outer wall: 20 gauge (.036"/.9mm) steel Finish: Powder coated
Base:	Blow-molded, high-density polyethylene Steel reinforced caster channels Caster mounts located outside of cart body footprint to provide counterbalance to full-extension drawers
Corner Extrusions:	3 channel PVC .125 (3mm) wall thickness
Work Surface:	.125" (3mm) ABS 19 ¹ / ₂ " x 20 ¹ / ₂ " (495 x 521mm) Molded in handgrip Raised on three sides 1 ⁵ / ₈ " (41mm) Front lip 1/2" (13mm) H. Usable work space: 16 ¹ / ₄ " x 17" (413 x 432mm) Molded in pencil holder, pill/paper clip holders
Casters:	5" (127mm) diameter with polyurethane tread 2 swivel-brake, 2 swivel-lock (converts from swivel to rigid) 200 lbs. (90kg) per caster 600 lbs. (270kg) per cart
Drawers:	50 lbs. (23kg) load rating per drawer
Body:	.032" (.8mm) coated aluminum Finish: Powder coated
Fronts:	.032" (.8mm) coated aluminum Finish: Powder coated
Pull:	Polymer
Slides:	Zinc-Plated Steel Load Rating: 100 lbs. (45kg)/set
Lock:	Bright Nickel Type 3 G Cam. 7/8" (22mm) Cylinder 2 Keys Coded on lock and keys

All Metro Catalog Sheets are available on our Web Site: www.metro.com



InterMetro Industries Corporation

North Washington Street, Wilkes-Barre, PA 18705
Phone: 570-825-2741
Fax: 570-825-2852

L03-274
Printed in U.S.A. 2/09

Information and specifications are subject to change
without notice. Please confirm at time of order.

Copyright © 2009 InterMetro Industries Corp.

For Product Information:
U.S. and Canada: 1.800.433.2232

Latin America: 1.561.333.3824
Europe: +31.76.587.7550

Asia/Pacific: +65.6567.8003
Middle East/Africa: +971.4.811.8286