



Item # \_\_\_\_\_

We put space to work.

Job \_\_\_\_\_

## Lionville® Touchpad Advanced

Certain applications have more advanced requirements to keep supplies secure and carrying a key is simply not convenient. The Lionville advanced touchpad provides features that control more authorized users via a 4-14 digit user identification number or the option to scan an authorized employee badge. The touchpad has an LCD screen to provide visual feedback and is battery operated, so there is no need to have dedicated outlets. It is backed up with a mechanical key lock should the need arise.



Advanced Touchpad

### Features Include:

- LCD screen with backlit display
- Controlled substance secondary locking control (up to 3 drawers max.)
- 6000 unique codes to support User/Supervisor identification numbers, proximity ID cards or proximity card's facility code
- Auto-Relock timer – default 5 minutes, adjustable via software from 1 second to 18 hours, or can be disabled
- Motion sensor timer – restarts auto-relock timer countdown
- Available Access Denied lockout timer – disables touchpad for a set time after repeated unauthorized entry attempts, programmable via software (feature is disabled as factory default, programmable 1 to 99 minutes)
- Battery operated on six replaceable D-Cell batteries
- Expected minimum battery life of one year
- Cart audit memory retains last 15,000 access events

### Optional proximity card access:

- Exclusive Facility Code Access – eliminates the need to set up and manage all individual user cards
- Low (125 kHz) or High-Frequency (13.56 MHz) integrated card readers
- Individual Card Code Access – control access to authorized group of users

### Optional software management:

- LockView® 5Pro software includes license for 1 server and 1 client
- USB connection from facility's computer to chart
- Facilitates faster fleet updates of user adds/deletes and audit trail information
- Required for Auto-Relock and Access Denied timer adjustments and audit trail capture



Catalog Number	Description
LMX420 <sup>F</sup>	Lionville 400/800 Advanced LCD Keyless Entry Touchpad
LMX420-6 <sup>F</sup>	Lionville 600 Advanced LCD Keyless Entry Touchpad
LMX423	Lock Management Software, Lockview 5Pro, w/1 client and 1 server license
LMX424	Lock Management Software, Basic, or additional license for LMX423
LMX430LCDPHF*	High-Frequency (13.56 MHz) Proximity Card Reader (works with LCD Touchpad)
LMX430LCDPLF*	Low-Frequency (125 kHz) Proximity Card Reader (works with LCD Touchpad)
LMXPROXCRDHF	High Frequency PROXIMITY CARD, 13.56 MHZ
LMXPROXCRDLF	Low Frequency PROXIMITY CARD, 125 KHZ

<sup>F</sup> Factory Installed

\* Proximity card readers are compatible with most industry standard data formats. In some cases, a sample card may need to be submitted to verify compatibility. Contact your Metro representative.

All Metro Catalog Sheets are available on our website: [www.metro.com](http://www.metro.com)



**InterMetro Industries Corporation**  
 North Washington Street, Wilkes-Barre, PA 18705  
 Product Information. U.S. and Canada: 1.800.992.1776  
 Outside U.S. and Canada: [www.metro.com/contactus](http://www.metro.com/contactus)

LO2-226  
Printed in U.S.A. 3/19

Information and specifications are subject to change without notice. Please confirm at time of order.

Copyright © 2019 InterMetro Industries Corp.



Lionville Touchpad Advanced

37.51



We put space to work.®

# Lionville Touchpad Advanced

## LockView® 5Pro software specification for Lionville Advanced Touchpad:

Lockview software is intended to be installed on a facility's computer that is capable being mobile to allow connection via USB to an individual cart.

### Minimum System Requirements:

- Windows Vista, 7, 8, 8.1, 10, Server 2008/2012 and R2 versions
- 4GB RAM - Processor 2.0 GHz or higher (8GB RAM recommended)
- 4GB Hard drive space
- SQL Server Standard, Enterprise, or SQL Express 2008/2012/2014 and R2 versions (optional, see note)
- ODBC connection required to Server (optional, see note)
- Local Administrator Rights are required to install and register the software
- .Net 4.0 Client Framework
- Minimum monitor resolution: 1024 x 768
- Signed 32 bit and 64 bit WHQL drivers
- Supports both 32 and 64 bit Operating Systems

**Note:** LockView will create a local MS Access database, which will be sufficient for standalone usage. If multiple clients are logging into the database, an SQL Server is recommended to ensure database integrity.

### Software Features:

- Includes USB connection cable
- Manages a database of authorized users and supervisors including user name, user's ID #, and user's access card number
- Manages database of supported carts and their settings
- Programmable access denied lockout feature
- Programmable auto-lock timer
- Maintains a comprehensive audit trail of cart access attempts
- eReports can be setup to automatically create and send audit trail re-ports to a list of email addresses daily, weekly or monthly
- Time based restrictions for access control, individual or group.
- Option to require two different credentials to gain access – i.e. card and ID number
- Alarm volume adjustment settings

### Software Benefits:

- Provides more efficient management of users and cart settings from a single source
- Eliminates the redundant task of re-entering users and cart settings via the touchpad on each cart
- Visibility to cart access can provide a higher level of security and minimize diversion
- Provides consistency in authorized users
- Standardizes settings across a fleet of carts

